


OUTREACH

LAND MOBILE UHF CB & CELLULAR ANTENNAS



www.benelec.au

Benelec Pty Ltd. 17 Byrnes St, Botany NSW 2019, Australia +61-2-8397-3333 | reception@benelec.com.au



EST. 1978 V





SKU	02635	02638	026381K	024579RK	024581RK
FREQ.	477 MHz	477 MHz	477 MHz	• 690–960 • 1710–2700 • 3500 – 3700 MHz	• 690–960 • 1710–2700 • 3500 – 3700 MHz
GAIN	3 dB / 6.5 dB	3 dB / 6.5 dB	3 dB / 6.5 dB	3 dB / 7.5 dB	3 dB / 6 dB
RMINATION	Stud mount with 5m RG58C/U + FME Socket with UHF Plug Adaptor	Spring Base with 5m Low Loss RG58 with SMA Plug and UHF Adaptor	1/2" Stud mount with 5m RG58C/U + FME Socket with UHF Plug Adaptor	Spring Base with 5m Low Loss RG58 with SMA Plug	1/2" Stud mount with 5m Low Loss RG58 with SMA Plug

www.benelec.au

mages are not to scale.

Innovative Radio Technology



Mirror Bracket SKU: 02728



Adjustable Lip Bracket SKU: 027303



Z Bracket Guard Mount SKU: 02734



Super Sucker Mag Base Kit SKU: 027423



Wrap Around Bracket 50mm SKU: 027314



Wrap Around Bracket 63mm SKU: 027315



SKU: 02732



Standard Bull Bar Bracket Ultra Heavy Duty Fold Down BB Mount SKU: 027323



Fold Down Gutter Bracket SKU: 02714S



Heavy Duty Gutter Bracket SKU: 02726S



UHF Switch - 1 in x 2 out SKU: 1738101B



M Base 5m RG58 to FME socket SKU: 10109

GPI Radiating Patterns

Ground Plane Independent (GPI) antennas can be mounted anywhere on the vehicle. These antennas work independently of the vehicle body, and as such they provide consistent performance all the way around the antenna.



Mounting Tips & Advice

- For better performance locate the antenna higher on the vehicle.
- Brackets and antenna mountings are to be secured properly.
- · Antennas must be mounted vertically, this is particularly important with higher gain antennas.
- Avoid affixing any object to the antenna as it could affect the performance of the communications system.
- Ground Plane antennas need to be fitted direct to vehicle panels, as bracket mounting will compromise the
- Do not mount antennas close to each other. Min distance should be 70cm between antennas. The further apart the two antennas, the better the performance of each respective antenna.
- Do not mount antennas closer than 70cm to any metal vertical surface.
- Do not mount antennas operating on the same band, at the same horizontal level unless a switch selects them.

Connector Advice

We recommend to add a thread locking adhesive (eg Loctite 242 Blue - Threadlocker Medium Strength) at the interface between the cable connector (FME socket) and the UHF plug adaptor as it's possible for this connection to vibrate loose over time.

Exposed connectors should be sealed with self amalgamating tape such as Benelec P/N 5052219BK or equivalent.

Cable Advice

Care must be taken to not damage, cut or crush the coaxial cable when routing it to the transceiver through a vehicle. We recommend to seal any points where the cable enters the vehicle.

Available from:

